TiVo Remote Control Reference

MICROPHONE for Voice Search.

POWER turns the TV on or off.

INPUT selects the input for your TV.

GUIDE takes you to the on-screen Guide.

VOL controls the volume on your TV.

CH changes the channel up and down.

TIVO takes you to the main menu.

MUTE turns the sound on or off.

i shows more information about what you're watching.

CONTROLLER navigates using the UP, DOWN, LEFT or RIGHT areas.

OK, in the center of the Controller, accepts the current selection.

DVR lets you schedule new recordings and access existing recordings.

BACK opens the main menu or returns to the previous screen.

VOICE SEARCH finds your shows. On some remotes VOICE SEARCH looks like this:

LAST goes to the last viewed channel.

APPS takes you to all your apps.

NETFLIX launches the Netflix app.

NUMBER BUTTONS enter numbers (e.g., channel numbers or Parental Controls PIN).

LHTC Broadband tv